




	OPERATING GUIDE GPL TRONIQUE	GU 7051 EN A www.alma.alma.fr
---	---	---


This document sketches out the main menus (please refer to operating manual MU 7051 EN for further information).

USING THE BUTTONS


-  - Come back to the previous stage
 - Increment the blinking figure
-  - Choose the menu option
 - Access to the following figure
-  - Validate the displayed option
 - Validate the entry data

RUN A DELIVERY


1. PREPARE THE DISCHARGE



▲ CHOOSE THE PRODUCT






▲ CHOOSE PRESET OR FREE DISCHARGE



▲ SET THE VOLUME ⚠ with PRESET MODE



-  Change the blinking figure value
-  Access to the following figure
-  Validate the entry data

2. CARRY OUT THE DISCHARGE

▲ START THE DISCHARGE



The discharge may be interrupted by several situations

► APPEARANCE OF A FAULT AND DISPLAY OF AN ALARM




-  Continue or stop the discharge (§3)

► INTENTIONAL INTERRUPTION OF THE DISCHARGE



-  Continue or stop the discharge (§3)


▲ DISPLAY DELIVERY INFORMATION



3. CONTINUE OR STOP THE DISCHARGE



▲ CONTINUE THE DISCHARGE




-  Start the discharge (§2)

▲ STOP THE DISCHARGE



-  Temperature is displayed ⚠ with active option
- 👉 If temperature is not displayed, enter the value
-  Print the delivery ticket §4 ⚠ with active option

4. PRINT THE DELIVERY TICKET



Prepare the discharge §1

MEANING OF SYMBOLS

- ▲ Mandatory action
- ▲ Optional action (depends on configuration choosen)
- Event during delivery
- 👉 Action by operator

LIST OF ALARMS

		DISPLAY	MEANING	ACTION
USER		STOP DISCHARGE	Intentional interruption of discharge	Continue or end the delivery
		COMMUNICATION DEFAULT	Communication with the printer lost	Check the connection cable, on-off switch and fuse
		POWER SUPPLY PROBLEM	Power outage during delivery	Check the cause / Restore power supply
		ZERO FLOW DEFAULT	Zero flow	Check if the pulse transmitter is powered (red indicators)
		LOW FLOW DEFAULT	Low flowrate (lower than minimal flowrate)	Check if the pulse transmitter is powered (red indicators)
		HIGH FLOW DEFAULT	High flowrate (greater than maximal flowrate)	Check the parameters / Reduce flowrate
		DATE AND TIME LOST	Loss of date and time	Set date and time in SUPERVISOR MODE
		METERING PROBLEM	Metering problem with the measuring device	Check if the pulse transmitter is powered (red indicators)
		PTO DEFAULT	Coherence failure with power take-off	Check the power take-off status in driver's cab
		HOSE BURST	Flowrate variation caused by a hose burst	The delivery is stopped automatically
REPARATOR	NON BLOCKING	DIARY DEFAULT	Reset of the events diary	Acknowledge the alarm, check the date in supervisor mode (supervisor key)
		DISPLAY DEFAULT	Problem with display card	If steady alarm, substitution of the display card
		WATCHDOG DEFAULT	Fault with display or power card or AFSEC+ card	Switch on-off the MICROCOPT+ / If steady alarm, substitution of the faulty card
		TOTALISER LOST	Loss of totaliser	Substitution of the backup battery
	BLOCKING	TEMPERATURE DEFAULT	Temperature determination failure	Check the temperature probe / If steady alarm, see a reparator for trouble shooting
		MEMORY LOST (PILE)	Loss of saved memory	Substitution of the backup battery
		MEMORY LOST	Error on SIM memorization	Enter and exit the METROLOGICAL MODE / If steady alarm, substitution of the backup battery
		COEFFICIENTS DEFAULT	Deviation between coefficient LF/HF greater than 0.5%	Modification of the low flow coefficient (K1)
		PROM DEFAULT	Loss of software or resident integrity	Substitution of the AFSEC+ electronic card
		RAM DEFAULT	Saved memory fault	Substitution of the AFSEC+ electronic card
		EEPROM MEMORY LOST	Loss of metrological configuration	Substitution of the AFSEC+ electronic card
		MEMORY OVER LOADED	SIM memory full	Substitution of the AFSEC+ electronic card